


Engine and Transmission Harness (6.0L) - 6 of 7



- (1) Engine Coolant Temperature (ECT) Sensor Connector -- B39
- (2) Heated Oxygen Sensor (HO2S) Bank 2 Sensor 1 Connector -- B166
- (3) Engine Block Ground -- G112
- (4) Knock Sensor (KS) Left Connector -- B65