


Instrument Panel Wiring -- Left Side (After 12/06)



- (1) Speaker - LF Tweeter Connector -- B112
- (2) RHS and LHS I/P Harness Crossover Connector 2 -- X228
- (3) RHS and LHS I/P Harness Crossover Connector 1 -- X229
- (4) Inflatable Restraint I/P Module Connector 1 -- A62-X1
- (5) I/P Data link Connector -- X95
- (6) Inflatable Restraint I/P Module Connector 2 -- A62-X2