


## Instrument Panel Wiring - Steering Column (Right Hand Drive)



- (1) Windshield Wiper/Washer Switch Connector -- S247
- (2) Ignition Key Cylinder Lamp Connector -- E105
- (3) Turn Signal Multifunction Switch Connector -- S231
- (4) Inflatable Restraint Steering Wheel Module Coil Connector -- X116-X1
- (5) Steering Angle Sensor Connector -- X227
- (6) Headlamp and Dimmer Panel Switch Connector -- S125
- (7) Inflatable Restraint Steering Wheel Module Coil Connector -- X116-X2
- (8) Body Control Module (BCM) Connector -- A15-X1 to A15-X7
- (9) Courtesy Lamp - Right Footwell Connector -- E105
- (10) Accelerator Pedal Position (APP) Sensor Connector -- B22
- (11) Data Link Connector (DLC) -- X40
- (12) Brake Pedal Position (BPP) Sensor Connector -- B165
- (13) Theft Deterrent Control Module Connector -- A171
- (14) Ignition Switch Connector -- S149